

CCTV Recording In Operation

**System Operated
By**



**PRIME
DIGITAL**

Advanced CCTV

0845 045 0313


Chapter 5

Video substream (dual stream) operation


Substream is a lower resolution video which directed to reduce Client PC usage (CPU, network) for live view display. For example, main stream for recording can be set to 1920x1080 at 30fps and substream to 640x480 at 15fps, that would provide much lower load for Client PC to display video stream. This allow to have a high quality recordings, but still be able to view many video stream on low performance Client PC and limited bandwidth.

Client application will detect substream availability and will optimize operation of high and low resolution video streams automatically. For example: when a single video stream placed on a full screen then the software will display high resolution video, when multiple cameras displayed then lower resolution video will be displayed.

Client application has following visual indication on live view screen for substream:




A footer for high resolution video stream include an "H" letter icon.



Low resolution video stream include an "L" letter icon.

"H" and "L" icon absence indicates a lack of substream availability

There is also ability to force high or low resolution video stream (-s) on demand. Right click on a video stream live view screen, select "Video Substreams".




Note: Please refer [supported camera list](#) column "substream".

Substream must be activated on the camera via web browser. Please verify camera's performance to make sure sub-stream can be handled by the camera along with the others features enabled on the camera.


End of video sub-stream operation

Layouts



Create custom Layouts by grouping cameras from different VMS Servers/Locations into groups for more efficient monitoring, and better management.

For example group together all outdoor cameras from different location or all POS cameras from all registers.






Individual Layouts can be activated by double-click on them with the mouse.

Users now can perform playback and other function by Right-click on the camera of their interest.

Note that empty screens by default are filled with available cameras. You can disable this feature by selecting Tools->Options and choosing Screen mapping tab on appeared dialog, Set Automatic mapping mode to "disabled".

Layout Sequences

When Layouts are created, they can be used for Sequencing.
To create Sequences Right mouse click on Layout Sequences.



Manage priority or remove layouts of your choice.

Choose given Layouts for adding them in a sequence.

Set time interval between layouts

End of layouts


Map module

VMSMap allows you to quickly and conveniently locate cameras for viewing placed on Google Map and/or on your own floor plans added in JPEG format.


To start this module use this toolbar button:



Right click the map and use context menu commands to configure and control map features.



- **Add New Camera Marker** – this item will add camera marker in place where menu has been called. There will be shown list of servers and cameras after choosing this menu item. After adding new marker you can double click on marker to activate matching camera. To remove marker right click on it and choose according popup menu item.
- **Add New Map Link** – inserts on current map link on the new or already created map. Double click will change current map on the linked map. To remove this link use right click on it and choose according menu item.
- **Goto Map** – navigate to other maps in appeared list.
- **Create New Map From File** – add new map from JPEG image file, which will be used as background.
- **Fit To Window** – JPEG map will strain on window maintaining it's aspect ratio.
- **Save Current Position** – used in Google map to saving it's current position.
- **Set Current Map As Startup** – set current map as startup map. Selected map will be loaded when starting to view this map module.
- **Rename Current Map** – rename currently selected map.
- **Remove Current Map** – delete currently selected map.



End of map module


Chapter 6

How to Playback Video

To playback recorder video
Right click on your server name
Choose tasks
Open archive

You can also

Right click on any camera view and
Choose open archive



Your archive pane will now open

Playback Window Structure -

Now that you are in the playback screen, the structure pane on the left lists all of the cameras that you have recordings for

To Navigate through the Video -

Double click on the camera you wish to playback (This camera will now appear with footage on the video screen)



The solid **green line** on the bottom represents time. The **light green lines** represent recorded video. The **orange lines** represent motion information.

There are basic VCR controls on the bottom of the playback screen, which you can use to play, pause, forward, and rewind.

Fast forward & Rewind

You have a jog dial on the bottom of the screen, which you can drag in either direction to browse through your video in high speeds.

Another way to fast forward is to use the arrow controls on top of the screen in which you can define how many increments of time you would like to move through the video.




Playback Motion Only-



Located at the top of your Archive Pane, there are two buttons that allow you to seek video with actual motion in return saving you time.

With the camera you wish to review selected and showing in your video screen
Choose either “seek previous motion” or “seek next motion”





Smart Search

You can also search through video not only by motion in the screen, but also by ***motion in a specific part of your camera screen***. Through Luxriot’s playback screen, you can define a specific object in your view, or define a path, and seek through motion only in that specific region. This process is very commonly referred to as “smart search”.

Define motion of interest

Click on the navigation menu at the top of the playback screen

Click on “Define region of motion interest”.



While having the left button continuously pressed, drag the mouse over the area you would like to see motion in (This will create a grid in that area). You can also select multiple regions.



Click on “seek to previous motion”

or “seek to next motion”

to search through motion in the defined area or areas.


End of Playback Video

Export Video


To export video, you first have to select the section of recordings that you want to export to a different location (This will also prevent it from getting overwritten). To select video

Click on Edit at the top of the playback screen

Click on Export Wizard




Video + Audio export available only for ASF and WMV formats.




Choose which camera to export.

Choose compression.


Choose subtitles.



Choose which Audio stream you want to export along with video.



Click next.




Select the start and finish times of the video clip that you want to export.

The Wizard will guide to the next step for you do designate to which drive or folder to save the export video.

Note: To play back the Luxriot AVI file, a codec (a small executable file) will have to be installed in order for your media player to recognize the Luxriot video file. The codec can be downloaded from <http://www.Luxriot.com/downloads.html>

Export Batch


set all necessary parameters and before start export, the wizard shows you the Export Batch window. The export Batch Window allows you add multiple export tasks.



Export Snapshots

Another way to export video is to save one frame at a time, like a snapshot.

First pause the video on the picture that you would like to copy,
Click on edit
Choose “save current frame as...”
Pick a location and file name for your image and
Click save.




Now you will have the image stored so that you can print, e-mail, or enhance that snapshot.

Quick snapshot save and current visible frame save


The Quick save feature provides you the option to quick save video snapshot to a pre-define location with a single keyboard shortcut.

Prior using the “quick save current frame” the Quick save properties must be configured to pre-define the save location.




Setup preferred directory for saving the snapshots.

Quick snapshot can be saved by menu or short keys




The same procedure applies for Digital PTZ visible Frame.




End of Export Video

Watermark Validator

The application can be started from Start menu: Start -> Programs -> Luxriot Digital Video Recorder -> Tools -> VMS Server Watermark Validator



To check the watermark it is necessary to drag and drop one or more file onto application window.



End of Watermark validator.